



(a)



(b)



(c)

**FIGURE 19-27** (a) A 3-prong plug, and (b) an adapter (gray) for old fashioned 2-prong outlets—be sure to screw down the ground tab. (c) A polarized 2-prong plug.

**CAUTION**  
*Black wire may be either ground or hot. Beware!*

Grounding a metal case is done by a separate ground wire connected to the third (round) prong of a 3-prong plug (Fig. 19-27a). Never cut off the third prong of a plug—it could be deadly.

Why is a third wire needed? The 120 V is carried by the other two wires—one **hot** (120 V ac), the other **neutral**, which is itself grounded.<sup>†</sup> The third “dedicated” ground wire with the round prong may seem redundant. But it is protection for two reasons: (1) it protects against internal wiring that may have been done incorrectly; (2) the neutral wire carries normal current (“return” current from the 120 V) and it does have resistance; so there can be a voltage drop along it—normally small, but if connections are poor or corroded, or the plug is loose, the resistance could be large enough that you might feel that voltage if you touched the neutral wire some distance from its grounding point.

Some electrical devices come with only two wires, and the plug’s two prongs are of different widths; the plug can be inserted only one way into the outlet so that the intended neutral (wider prong) in the device is connected to neutral in the wiring. For example, the screw threads of a lightbulb are meant to be connected to neutral (and the base contact to hot), to avoid shocks when changing a bulb in a possibly protruding socket. Devices with 2-prong plugs do *not* have their cases grounded; they are supposed to have double electric insulation. Take extra care anyway.

The insulation on a wire may be color coded. Hand-held meters may have red (hot) and black (ground) lead wires. But in a house, black is usually hot (or it may be red), whereas white is neutral and green is the dedicated ground. But beware: these color codes cannot always be trusted.

Normal circuit breakers (Sections 18-6 and 20-7) protect equipment and buildings from overload and fires. They protect humans only in some circumstances, such as the very high currents that result from a short, if they respond quickly enough. Ground fault circuit interrupters, described in Section 21-8, are designed to protect people from the much lower currents (10 mA to 100 mA) that are lethal but would not throw a 15-A circuit breaker or blow a 20-A fuse.

<sup>†</sup>In the U.S., three wires normally enter a house: two *hot* wires at 120 V each (which add together to 240 V for appliances or devices that run on 240 V) plus the grounded *neutral* (carrying return current for the two hots). See Fig. 19-28 below. The “dedicated” *ground* wire (non-current carrying) is a fourth wire that does not come from the electric company but enters the house from a nearby heavy stake in the ground or a buried metal pipe. The two hot wires can feed separate 120-V circuits in the house, so each 120-V circuit inside the house has only 3 wires as discussed in the text.

**FIGURE 19-28** Four wires entering a typical house. The color codes for wires are not always as shown here—be careful!

